

VDBENCH Scripts: Configuring Host Storage

Dennis Martin

SNIA Emerald[™] Training

SNIA Emerald Power Efficiency Measurement Specification, for use in EPA ENERGY STAR®

July 14-17, 2014







- Volumes, or LUNs, need to be configured that match the VDBENCH scripts, corresponding to the "SD" storage definitions in the VDBENCH script.
- For these tests, we use raw volumes which means that there is no filesystem on the volumes
- Each storage system has different ways to create LUNs and volumes, set RAID levels, etc.
- We have found that more LUNs, up to a point, are better with the SNIA Emerald testing rather than creating one large LUN.




Host View #1



	DISKS						^
Servers	All disks 5	total				TASKS	•
Volumes Disks	Filter		◄ (ii)	₩ ▼		\odot	
Storage Pools	Number Virtual	Disk Status	Capacity Unalloca	ted Partition Read	Only Clustered	Subsystem	Bus
	▲ dmrtk-srvr		cupacity ondiroco		only	oubsystem	
	0	Online	238 GB 0.00 B	MBR			SAT
	1	Online	1.86 TB 1.86 TB	Unknown			iSC
	2	Online	1.86 TB 1.86 TB	Unknown			iSC
	3	Online	1.86 TB 1.86 TB	Unknown			iSC
	4	Online	1.86 TB 1.86 TB	Unknown			iSC
	C III >						>
	VOLUMES			STORAGE POO	L		
	Related Volumes	2 total	TASKS 🔻	Samsung SSD 840	PRO Series on dmrtk	-srvr-p TASKS	•
	Filter		 ۹ ۹ 	N	o related storage pool	exists.	
	A Volume	Status Prov	visioning Capacity Fr	e			

Host View #2





Host iSCSI Initiator



- Two paths are configured to this storage
- 10GbE connections running iSCSI

	iSCSI In	itiator Propertie	s	x
Targets Discovery	Favorite Targets	Volumes and Devices	RADIUS	Configuration
Quick Connect				
	on to a target usin arget and then click	g a basic connection, t Quick Connect.	type the IP	address or
Target:			Q	uick Connect
Discovered targets				
				<u>R</u> efresh
Name			Status	
iqn. 1992-08.com.	netapp:sn.4e87a51	2098511e49edd12	Connecte	d
iqn. 1992-08.com.	netapp:sn.a4a8512	6098411e49edd12	Connecte	d
To connect using a click Connect.	dvanced options, se	elect a target and then		Co <u>n</u> nect
To completely disco then click Disconne	nnect a target, sele :t.	ect the target and		Disconnect
For target properti select the target a	es, including configu nd click Properties.	ration of sessions,		Properties
For configuration o the target and the		l with a target, select		De <u>v</u> ices
		ОК	Cance	<u>Apply</u>



www.sniaemerald.com